

OPERATION TITLE:

ORIGINATOR NAME:

SOP No. RWM-DR-012 Effective Date: 03/25/2009 Revision No. 07

Last Revision Date: 03/04/2021 Page 1 of 4

COVERSHEET STANDARD OPERATING PROCEDURE

CHAIN OF CUSTODY PROTOCOL

Becky Blais

	Division of Rer	nce Coordinator nediation ediation and Wast	e Management
APPROVALS:			
Division of Remedia	ation Director:		
Carla J. Hopkins	Cala/Hope		Dec 21, 2021
Print name	Signature		Date
Bureau of Remedia	tion and Waste Manage	ement Director:	
Susanne Miller	Harm		Dec 23, 2021
Print name	Signature		Date
QMSC Chair:			
Kevin Martin	Kim E Mot		Dec 23, 2021
Print name	Signature		Date
Department Commi	ssioner:		
Melanie Loyzim	Mulami 188 Signature		Dec 23, 2021
Print name	Signature		Date
DISTRIBUTION;			
() Division of RemediationBy:			Date:



SOP No. RWM-DR-012 Effective Date: 03/25/2009 Revision No. 02

Last Revision Date: 03/04/2021 Page 2 of 4

1.0 APPLICABILITY

This Standard Operating Procedure (SOP) applies to all programs in the Maine Department of Environmental Protection's (MEDEP) Division of Remediation (DR). It is also applicable to all parties that may submit data that will be used by the MEDEP/DR.

This SOP is not a rule and is not intended to have the force of law, nor does it create or affect any legal rights of any individual, all of which are determined by applicable statutes and law. This SOP does not supersede statutes or rules.

2.0 PURPOSE

The purpose of this document is to describe the MEDEP/DR procedure for sample chain of custody (COC).

3.0 RESPONSIBILITIES

All MEDEP/DR Staff must follow this procedure when performing this task. All Managers and Supervisors are responsible for ensuring that their staff are familiar with and adhere to this procedure. MEDEP/DR staff reviewing data by outside parties are responsible for assuring that the procedure (or an equivalent) was utilized appropriately.

4.0 DEFINITIONS

- Chain of Custody Form A document detailing who is legally responsible for samples at any point in time from collection until the sample is received by the laboratory.
- Custody--A sample is "in custody" when: 1) the sample is in the sampler's possession, or 2) the sample was in the sampler's possession and then secured by the sampler to prevent tampering, or 3) the sample is placed in a designated secure area.
- Secure Area—An area in which entry is limited by keyed lock to a designated population.

5.0 GUIDELINES AND PROCEDURES

5.1 INTRODUCTION

This SOP establishes the proper methods for implementation of sample chain of custody documentation and procedure. Proper sample chain of custody procedures are essential to collecting valid information which may be used in any legal proceedings. Additionally, samples must be stored properly until delivery to the laboratory to assure proper preservation of the sample, and to avoid introducing contamination from ambient conditions. Transportation to the laboratory should be arranged as quickly as possible to avoid exceedances of holding times for analysis.

Failure to maintain possession in the ways outlined in this SOP would constitute a break in sample custody and would likely discredit the sample(s) as use of evidence in administrative or



SOP No. RWM-DR-012 Effective Date: 03/25/2009 Revision No. 02 Last Revision Date: 03/04/2021

Page 3 of 4

court proceedings and the validity of the sample. The sampler must assume that all samples collected will someday be used as evidence and treat the task of sample custody accordingly.

Sample custody begins immediately after a sample is collected. The sampler who collected the sample is responsible for the preservation and integrity of the sample(s) until that responsibility is transferred to someone else and documented with the COC form. This COC form then travels with the sample(s) and is used to document any other transfers of custody.

5.2 CHAIN OF CUSTODY

The COC form will document the information identifying the sample and a record of the relinquishing and receiving individuals. All samples from different locations must be given separate identifiers. Sample identifier, analysis requested, date and time, type and size of container, and any added preservative must be indicated on the COC for each sample. Date, time, and name written legibly, with signature, must be included in all entries outlining a change in the position of samples. Samples which may have high levels of contamination or may be hazardous to health should be indicated as such in the comments section of the COC. The COC should also indicate who, with contact information, will receive the completed data package.

MEDEP/DR personnel will use the COC provided by the laboratory conducting the analysis of the samples, making sure to fill it out completely and accurately. Once received by the laboratory, the laboratory will use a separate internal COC for documenting access to the sample during analysis.

5.3 OVERNIGHT STORAGE

Whenever possible, all samples will be taken to the laboratory performing the analyses on the same day the samples are collected, or given to courier service to transport the samples to the laboratory. If it is impossible to check in samples at the laboratory the same day, the samples should be placed in a secure area, following appropriate protocol for sample preservation (such as cooling to 4° C).

During the winter months the sampler must make sure the samples are kept from freezing while being stored. Samples should not be stored in an area that has ambient conditions that would cross contaminate the samples, such as a garage with large amounts of gasoline storage.

If samples are not checked into the laboratory the same day as collected, the storage location and means of providing security shall be documented in the Sampling Event Trip Report (SETR) (See MEDEP/DR SOP# RWM-DR-013 - Documentation of Field Activities and Development of A Trip Report).

5.4 USE OF COURIER SERVICES

If samples are given to a common carrier, such as United Parcel Service, or FedEx, the last person who has custody of the samples will sign off on the COC, and state that the samples will be given to a common carrier on the COC. The COC is then placed in the shipping container with the samples, and the shipping container sealed with a tamper proof custody seal, and given



SOP No. RWM-DR-012 Effective Date: 03/25/2009 Revision No. 02 Last Revision Date: 03/04/2021

Page 4 of 4

to the courier. The COC samples while in the courier's possession is the shipping record used by the courier. All samples should be shipped for next day delivery; if shipping samples on a Friday, make sure the laboratory is staffed for Saturday delivery.

The laboratory receiving the samples must check the integrity of the shipping container seal upon receipt. If the seal is broken, the laboratory staff receiving the container must indicate the broken seal on the COC with the samples.

5.5 SAMPLE CONTAINER TAMPER PROOF SEALS

Depending on the data quality objectives (DQOs), it may be necessary to place tamper proof tape on the actual jar at the time of collection as an extra step in assuring the integrity of the sample. This may be required for projects in which the data will be used for criminal enforcement cases. The project SAP will outline the need for individual sample protection, or any other special custody requirements for meeting project specific DQOs.

5.6 DISPOSITION OF COMPLETED CHAIN OF CUSTODY

Upon drop off of the samples at the laboratory, the laboratory should retain the original copy of the COC, and provide a copy to the sample transporter. If using common courier for transport, the laboratory should send a copy of the COC after receipt of the samples. A copy of the COC should be included with the trip report, as outlined in MEDEP/DR SOP# RWM-DR-013 – Documentation of Field Activities and Development of a Trip Report.

6.0 DOCUMENTATION

This sampler must record all information pertaining to the sample in his/her field notebook (following MEDEP/DR SOP# RWM-DR-013 - Documentation of Field Activities and Development of a Trip Report), and make sure that all the pertinent information is accurately transferred to the COC.

012-chain-of-custody-FINAL-2021 - B Blais

Final Audit Report 2021-12-23

Created: 2021-12-20

By: Lindsay Caron (LINDSAY.ER.CARON@MAINE.GOV)

Status: Signed

Transaction ID: CBJCHBCAABAAoE358DpAobbR2-H3kQtM_t5feKDpB7D6

"012-chain-of-custody-FINAL-2021 - B Blais" History

- Document created by Lindsay Caron (LINDSAY.ER.CARON@MAINE.GOV) 2021-12-20 2:34:48 AM GMT- IP address: 198.182.163.115
- Document emailed to Carla J. Hopkins (carla.j.hopkins@maine.gov) for signature 2021-12-20 2:36:05 AM GMT
- Email viewed by Carla J. Hopkins (carla.j.hopkins@maine.gov) 2021-12-21 9:28:29 PM GMT- IP address: 104.47.65.254
- Document e-signed by Carla J. Hopkins (carla.j.hopkins@maine.gov)

 Signature Date: 2021-12-21 9:30:30 PM GMT Time Source: server- IP address: 198.182.163.115
- Document emailed to Susanne Miller (susanne.miller@maine.gov) for signature 2021-12-21 9:30:33 PM GMT
- Email viewed by Susanne Miller (susanne.miller@maine.gov) 2021-12-23 3:31:13 PM GMT- IP address: 104.47.65.254
- Document e-signed by Susanne Miller (susanne.miller@maine.gov)

 Signature Date: 2021-12-23 3:31:24 PM GMT Time Source: server- IP address: 184.153.146.117
- Document emailed to Kevin Martin (kevin.martin@maine.gov) for signature 2021-12-23 3:31:26 PM GMT
- Email viewed by Kevin Martin (kevin.martin@maine.gov) 2021-12-23 6:15:43 PM GMT- IP address: 104.47.64.254
- Document e-signed by Kevin Martin (kevin.martin@maine.gov)

 Signature Date: 2021-12-23 6:17:29 PM GMT Time Source: server- IP address: 73.16.27.248
- Document emailed to Melanie Loyzim (melanie.loyzim@maine.gov) for signature 2021-12-23 6:17:30 PM GMT



Email viewed by Melanie Loyzim (melanie.loyzim@maine.gov) 2021-12-23 - 7:12:19 PM GMT- IP address: 104.47.64.254

Document e-signed by Melanie Loyzim (melanie.loyzim@maine.gov)

Signature Date: 2021-12-23 - 7:12:32 PM GMT - Time Source: server- IP address: 198.182.163.121

Agreement completed.

2021-12-23 - 7:12:32 PM GMT